


For use in Hong Kong, the Philippines and Singapore only.  
 If you made your purchase in another country, please refer to that country's manual.  
[www.elecom.co.jp/global/download-list/manual/](http://www.elecom.co.jp/global/download-list/manual/)




1st edition, September 2017

Thank you for purchasing this product. This manual describes the operating instructions and safety precautions for using this device. Please be sure to read this manual carefully before using the device. After reading, keep the manual in a safe place for future reference.

## Package contents

Please make sure all components are included. We aim to ensure that all our products are carefully packaged. Should any item(s) be missing or damaged, immediately contact the dealer you purchased the product from.



Instruction manual (with warranty) - this document



## Safety Precautions (Be sure to always follow these precautions)

In order to prevent personal injury or damage to property involving you or any other people, please be sure to observe the precautions outlined below.

The following symbols show the degree of injury or damage which may result through incorrect use or failure to observe the precautions in the text.

|  |   |
|--|---|
|  | <b>Warning</b><br>This symbol indicates the possibility of death or serious injury.           |
|  | <b>Caution</b><br>This symbol indicates the possibility of bodily harm or damage to property. |
|  | This symbol indicates a "Prohibited" action which must not be performed.                      |
|  | This symbol indicates a "Mandatory" action which must be performed.                           |

|                |  |
|----------------|--|
| <b>Warning</b> |  |
|                | <p>Any person whose condition corresponds to any of the following should consult a doctor prior to use.</p> <ul style="list-style-type: none"> <li>People using an implanted medical electric device such as a pacemaker that is susceptible to electromagnetic interference</li> <li>People receiving treatment from a physician, or people who feel a particular abnormality in their body</li> <li>People with malignant tumors</li> <li>People with heart problems</li> <li>Pregnant women or those who have just given birth</li> <li>People with impairments in perception arising from advanced peripheral circulatory disorders due to diabetes.</li> <li>People with wounds on their skin</li> <li>People who require rest in bed</li> <li>People with body temperatures of 38 ° C or higher (at fever stage)</li> <li>* Example 1: Acute inflammatory symptoms (such as fatigue, chills, blood pressure fluctuations)</li> <li>* Example 2: Debilitated condition</li> <li>People with osteoporosis or those with acute (painful) disorders, such as spinal fractures, sprains, pulled muscles</li> <li>People with an abnormal backbone or those whose backbone is bent to the right or left</li> <li>People with a herniated disc</li> <li>People feeling a physical abnormality or those under treatment at medical institutions</li> <li>People who feel no effects despite using the device for a while</li> </ul> <p>Such use could cause an accident or poor physical health.</p> |

2

|                |  |
|----------------|--|
| <b>Warning</b> |  |
|                | <p>Any person whose condition corresponds to any of the following should consult a doctor prior to use.</p> <ul style="list-style-type: none"> <li>People whose doctors have prohibited them from massages</li> <li>* Example: People with thrombosis (embolism), serious aneurysm, acute varicose veins, various types of dermatitis or skin infection (including inflammation of subcutaneous tissues)</li> </ul> <p>Such use could worsen symptoms.</p> |
|                | <p>Do not use this device for any purpose other than the intended one. Do not use this device on your head, face, breast, belly, bony parts (such as knee or elbow) or genitals.</p> <p>Such use could cause an accident or injury.</p>  |
|                | <p>Do not press the roller or pressing point too hard during use.</p> <p>Such use could cause an accident or injury.</p>   |
|                | <p>People who are unable to express themselves or use the device by themselves. Do not allow children to use or play with this device. Keep this device out of reach of small children when using or storing the device.</p> <p>Otherwise, an accident, injury or device failure may be caused. If a person has swallowed a part, consult a physician immediately.</p>   |
|                | <p>Do not use the device by standing or sitting on the main unit.</p> <p>Otherwise, an accident, injury or device failure may be caused.</p>   |
|                | <p>Do not use this device simultaneously with any other therapeutic apparatus.</p> <p>Such use could cause discomfort or poor health.</p>  |
|                | <p>Do not disassemble, repair or modify this device.</p> <p>Fire or electric shock may be caused.</p>  |

## Caution

|  |  |
|--|--|
|  | <p>Do not use this device for longer than ten minutes in a day. Do not continuously use the device for longer than three minutes in any area.</p> <p>Such use could cause an accident or poor physical health.</p> |
|  | <p>Always hold the device with your hand when using the device.</p> <p>Otherwise, an accident, injury or device failure may be caused.</p>   |

3

|                |   |
|----------------|---|
| <b>Caution</b> |   |
|                | <p>If you experience any unusual physical sensations in your body during use, stop immediately and consult a physician.</p> <p>Such use could cause an accident or poor health.</p>                           |
|                | <p>After use, stop operation with the power button.</p> <p>Such use could cause an accident, injury, damage of the product due to the falling of the product.</p>   |
|                | <p>If a device failure occurs, stop immediately, turn off the power, and contact the dealer.</p> <p>Such use could cause an accident or injury.</p>   |
|                | <p>Do not use this device when:</p> <ul style="list-style-type: none"> <li>You are very tired;</li> <li>You are drunk;</li> <li>You have eczema.</li> </ul> <p>Such use could cause poor health.</p>          |
|                | <p>Do not use this device within one hour before or after a meal.</p> <p>Such use could cause poor health.</p>  |
|                | <p>Do not sleep during use.</p> <p>Such use could cause an accident or injury.</p>  |
|                | <p>Do not use this device in bed or under a blanket. Do not use this device near a fire such as a stove or while smoking.</p> <p>Such use could cause burning, overheating of the motor or a fire hazard.</p> |
|                | <p>Do not use this device when you are wearing hard objects such as jewelry like necklaces or watches.</p> <p>Such use may cause injury.</p>  |
|                | <p>Do not drop this device nor subject it to strong impacts.</p> <p>Such use may cause an electric shock, injury or device failure.</p>   |
|                | <p>Do not use thinner, benzene, alcohol or hot water to clean the device.</p> <p>Discoloration or deformation may be caused.</p>  |
|                | <p>Do not use the device in a wet or humid place such as the bathroom or in water.</p> <p>Such use may cause electric shock, device failure or fire.</p>  |
|                | <p>Do not use the device while driving a car, riding a bicycle or motorcycle.</p> <p>Such use could cause an accident or problem.</p>   |

4

|                |   |
|----------------|---|
| <b>Caution</b> |   |
|                | <p>Avoid touching the DC connector socket with any part of your body such as a hand or a finger.</p> <p>Otherwise, electric shock or device failure may be caused.</p>  |
|                | <p>Do not insert any metallic object in the DC connector socket.</p> <p>Otherwise, overheating or fire may be caused.</p>   |
|                | <p>Avoid excessive pulling or bending of the dedicated USB cable, or placing heavy objects on the cable.</p> <p>Otherwise, cable damage or breakage, fire or electric shock may be caused.</p>                                  |
|                | <p>Do not use the device if the dedicated USB cable is damaged, or the DC connector socket is loose.</p> <p>Otherwise, fire or electric shock may be caused.</p>  |
|                | <p>Do not use a travel converter or any other power converter to charge the device.</p> <p>Otherwise, overheating or fire may be caused.</p>  |
|                | <p>Do not charge in a car using the cigarette lighter receptacle or any other means.</p> <p>Otherwise, fire, overheating or device failure may be caused.</p>   |
|                | <p>Do not touch the cable with a wet hand.</p> <p>Otherwise, electric shock, device failure or accident may be caused.</p>  |
|                | <p>Do not use the supplied dedicated USB cable for any purpose other than charging the main unit.</p>   |
|                | <p>Do not charge this device when the main unit is wet.</p> <p>Such use may cause overheating, fire or electric shock.</p>  |
|                | <p>Please confirm that the power button works properly before use.</p>  |
|                | <p>When using for the first time, or when the device has been out of use for a long period of time, follow the instruction manual and confirm it operates normally and safely prior to use.</p>                                 |
|                | <p>Before use, make sure that there is no crack in the main unit and that the power button is not broken.</p> <p>Cracks and breakage affect waterproofing performance and may cause electric shock, device failure or fire.</p> |

5

|                |  |
|----------------|--|
| <b>Caution</b> |  |
|                | <p>Make sure the dedicated USB cable is connected securely when charging.</p> <p>If connected incompletely while charging, fire or an electric shock may be caused.</p>                              |
|                | <p>Be sure to hold the connector to pull out the dedicated USB cable from the main unit.</p> <p>Do not pull the cable. Otherwise, electric shock, short circuit or device failure may be caused.</p> |
|                | <p>Be sure to charge the battery at least once every three months.</p> <p>If the device is fully discharged, it may not be rechargeable.</p>   |
|                | <p>If a power failure has occurred while charging, immediately stop charging.</p> <p>Otherwise, electric shock, device failure or accident may be caused.</p>  |
|                | <p>When disposing of this product, please do so in accordance with the regulations of your municipality.</p>   |
|                | <p>Carefully read this instruction manual before use. Make sure there is no problem with this device before use.</p>   |
|                | <p>After use, clean the device for the next use and store it in a low humidity place.</p>  |

6

## About this product

### Purpose of use

This product is a device designed to make the user feel refreshed and relaxed by applying stimulation to their body with a motor-driven roller.


It is intended for home use.

### Usage time

The standard usage time is approximately ten minutes in a day. Continuous use for more than three minutes on one area could cause poor health. This product is equipped with a timer that will automatically power off the device about five minutes after the start of operation.

## Part names

### Main Unit



### Dedicated USB cable



2


## Preparation

Be sure to charge the battery fully on first use (following purchase or after a long period without use) or if the batteries have run out during use.

### Charging


- Connect the DC connector of the dedicated USB cable to the DC socket on the main unit.
- Connect Type-A USB connector of the dedicated USB cable to any of the USB ports shown below to charge the battery.

#### Main Unit



#### Connecting to a PC

USB 2.0/3.0 port of a PC conforming to the IEC60950 standard



9

Charging time: approximately 2 hours

- When fully charged, the LED indicator will stop blinking and stay lit.
- When charging has finished, disconnect the dedicated USB cable from the main unit, following the steps backwards from ② to ① for safety. Once the battery is fully charged, it can be used for approximately 3 hours.
- \* This will change depending on the type of operation and usage environment.

### CAUTION :

- Use of travel converters or other power converters for charging may cause overheating or fire.
- Do not charge the device when the DC connector socket of the main unit is wet.
- The device does not operate while charging.
- The operating time of a fully charged battery becomes shorter with repeated charging of the main unit. If the operating time becomes extremely short, the battery has reached the end of its life. However, the battery is not replaceable.

### LED light


The LED indicator status changes as shown below depending on the remaining battery power.

|                                 |                                     |   |
|---------------------------------|-------------------------------------|---|
| [0 to 30%]<br>強 (弱) (おまかせ)      | [30 to 80%]<br>強 (強) (おまかせ)         | <ul style="list-style-type: none"> <li>○ Light is off</li> <li>● Blinking</li> <li>● Light is on</li> </ul> |
| [80% or higher]<br>強 (強) (おまかせ) | [Charging complete]<br>強 (弱) (おまかせ) |   |
|                                 |                                     |   |


10

## How to use

### Press and roll the rollers over the entire area where you wish to apply the device.




### Press the pressing point onto the area where you wish to apply the device.




### Turn on the vibrator, then roll the rollers or press the pressing point.

- Turn on the power.  
Press and hold the power button for about one second. The device will turn on and the vibrator will start. The Weak mode LED light turns on.




11

- Select mode.  
Press the power button to select a mode during operation. When the power button is pressed, the modes change in the sequence shown below.



- Turn off the power.  
The device turns off automatically about five minutes after the start of operation.



**CAUTION :**

- If you feel pain during use, apply a towel or the like underneath the device.
- Do not leave the device in high temperature or humidity areas, under direct sunlight, nor within reach of young children.

### Recommended time of use


When your body is warm, such as after a bath. Since this product has waterproofing performance equivalent to JIS IPX6, it can be safely used on a wet body.

12

7

8

## Example of use




● : Example of use with pressing point  
 → : Example of use with rollers

13

## Care of this equipment

- If the device becomes dirty, remove the rollers and wash the device with shower water, etc.



After washing, wipe off any water and leave the device in a well-ventilated place that is not exposed to direct sunlight.

**CAUTION :**  
 Take care not to allow such as water to enter the Main Unit or the DC connector port.

- If the device is very dirty, remove the rollers and wipe off any dirt with a soft cloth slightly dampened with a small amount of neutral detergent that is diluted with warm water. Next, wipe the device with a cloth slightly dampened with water, then wipe it with a dry cloth.
- Do not use thinner, benzine, alcohol or hot water. Discoloration or deformation may be caused.

**CAUTION :**  
 After cleaning, store the device in a low humidity place. (Leaving the device in a humid place such as a bathroom may cause condensation or rust in the main unit, leading to a device failure.)



14

## How to store

Please keep this product in an environment that meets the following conditions.  
 Storage temperature: - 10 ° C to 60 ° C  
 Storage humidity: 20 to 85% RH

### Precautions on storage

- Please do not store in the following places.
  - Places exposed to direct sunlight
  - Places with high temperatures or high humidity, places near sources of moisture or with a lot of dust
  - Places with high levels of vibration
  - Places where chemicals are stored or corrosive gases are produced
- Keep out of reach of young children.
- When not in use for a long periods of time, please store in the fully charged condition and aim to maintain a normal temperature (10 to 30 ° C).
- Charge the battery at least once every three months. If the device is fully discharged, it may not be rechargeable.

| Check concerning gas                |   | To ensure many years of use. |  |
|-------------------------------------|---|------------------------------|--|
| Do you notice any of the following? | ● During charging or operation there are unusual sounds or vibrations | Stop use                     | To prevent accidents, turn off the power or unplug the dedicated USB cable, and arrange for the dealer to perform an inspection. |
|                                     | ● The Main Unit is abnormally hot                                     |                              |  |
|                                     | ● The Main Unit shows changes in shape or gives off a burning smell   |                              |  |

15

## Disposal

### Regarding the recycling of lithium-ion batteries



### Li-ion

This product contains a lithium-ion battery. Since lithium-ion batteries are recyclable valuable resources, we strongly encourage customers to recycle. When disposing of this product, please do so in accordance with the regulations of your municipality.

- When disposing of this product, do not disassemble the battery.
- Do not dispose of the device in regular household waste. Improperly disposed of lithium-ion batteries will break in the garbage truck, and can short-circuit, overheat and catch fire.


### How to remove the lithium-ion battery

Never disassemble this product except when disposing of it.

**Warning**  
 The following procedure is only for disposal of the product and is not to be used for repairs. The product will not be repaired if it has been disassembled.


- When there is charge remaining, please use until the battery is fully discharged.
- Using a screwdriver, disassemble according to the following procedure.

- Remove the silicone caps on the three screws on the main unit, then remove the screws.
- Remove the case cover.




16


- Remove the silicone caps, then remove the six screws that hold the internal cover.



- Remove the two screws that hold the battery.



- Cut the connector wires on the battery behind the circuit board one by one, starting from the black negative wire, with a wire cutter.
  - \* Be careful not to cut the wires together, which will cause a short circuit



- Remove the battery

- Be careful not to short-circuit the (+) and (-) terminals of the battery following removal, and fix tape over the terminals to insulate them.

17

## Troubleshooting

| When   | Cause   | Solution   |
|--|---|--|
| Motor sound is heard during operation                                      |   | This is normal and does not affect device performance.   |
| Device does not turn on  | You have not pressed and held the power button for about one second                 | Press and hold the power button for about one second. ➔ P.11   |
|  | The battery is insufficiently charged or charging has cut off                       | Charge the battery. ➔ P.9, P.10  |
|  | The battery is charging   | After the battery is fully charged, remove the dedicated USB cable and begin use. ➔ P.9 · P.10   |
| Device does not turn off   | You have not pressed and held the power button for about one second                 | Press and hold the power button for about one second. ➔ P.12   |
|  | The battery is insufficiently charged or charging has cut off                       | Turn off the device and charge the battery. ➔ P.9 · P.10   |
| The power quickly cuts off During use the power turns off                  |   | Charge the battery. If the device still does not work, it has failed internally. Stop using and contact the dealer. ➔ P.9 · P.10                         |
| The device cannot be charged   | The dedicated USB cable is disconnected   | Connect the dedicated USB cable. ➔ P.9 · P.10  |
|  | The device was stored for a long period of time and the battery is fully discharged | You cannot use the device any more. Charge the battery at least once every three months to prevent full discharge. ➔ P.15 · P.16 · P.17                  |
| The Weak mode and Strong mode LED indicators are blinking during operation |   | Turn off the device and charge the battery. If the device still does not work, it has failed internally. Stop using and contact the dealer. ➔ P.9 · P.10 |

18

## Product specifications

|   |  |
|---|--|
| Power source voltage                      | DC 5.0 V ± 5% (lithium-ion battery)                                |
| Built-in battery                          | 1000mAh * 1 * 2  |
| Number of charge cycles                   | Approx. 500 times * 1  |
| Charging time                             | Approx. 2 hours * 3  |
| Operating time                            | Approx. 3 hours (after fully charged) * 4                          |
| Rated power consumption                   | Approx. 2 W  |
| Timer                                     | Approx. 5 minutes  |
| Vibration speed                           | Strong: Approx. 6,200 times/min;<br>Weak: Approx. 5,400 times/min; |
| Waterproofing performance                 | Equivalent to IPX6 * 5   |
| Main Unit dimensions                      | Approx. 220 (H) x 82 (W) x 80.5 (D)                                |
| Cable length                              | Approx. 0.5 m  |
| Main Unit Weight                          | Approx. 260 g  |
| Material                                  | Main unit: ABS resin; Roller: Silicone rubber                      |
| Operating temperature and humidity ranges | 0 ° C to 40 ° C, 20 to 85% RH                                      |
| Storage temperature and humidity ranges   | - 10 ° C to 60 ° C, 20 to 85% RH                                   |

- \* 1 Based on JISC 8711
- \* 2 Overcharge, overdischarge, overvoltage protection functions installed
- \* 3 Approximate time when fully exhausted batteries are fully charged
- \* 4 This will change depending on the type of operation and usage environment
- \* 5 Except when charging

20

## Limitation of Liability

- In no event will ELECOM Co., Ltd be liable for any lost profits or special, consequential, indirect, punitive damages arising out of the use of this product.
- ELECOM Co., Ltd will have no liability for any loss of data, damages, or any other problems that may occur to any devices connected to this product.

## ELECOM CO., LTD.

|   |  |   |
|---|--|---|
| www.elecom.co.jp/global/  | ELECOM Korea Co., Ltd.<br>1F Suam Bldg. 1358-17, Seocho2-dong, Seocho-gu, Seoul 137-862, Korea<br>TEL : +82 (0) 2 - 1588 - 9514<br>FAX : +82 (0) 2 - 3472 - 5533<br>www.elecom.co.kr | ELECOM Sales Hong Kong Ltd.<br>2/F, Block A, 2-8 Watson Road, Causeway Bay, Hong Kong<br>TEL : +852 2806 - 3600<br>FAX : +852 2806 - 3300<br>email : info@elecom.asia |
| 新加坡商家(上海)商贸有限公司<br>上海市徐汇区肇嘉浜路1065甲号1603H室<br>電話 : +86 (0) 40 - 0867 - 3568<br>www.elecom.cn |  | ELECOM Singapore Pte. Ltd<br>33 UBI AVENUE 3 # 03-56,<br>VERTEX SINGAPORE (408868)<br>TEL : +65 6347 - 7747<br>FAX : +65 6753 - 1791                                  |

- Unauthorized copying and/or reproducing of all or part of this manual is prohibited.
- The specifications and appearance of this product may be changed without prior notice for product improvement purposes.
- When exporting this product, check the export regulations for the country of origin.
- Company names, product names, and other names in this manual are either trademarks or registered trademarks.

A customer who purchases outside Japan should contact the local retailer in the country of purchase for enquiries. In "ELECOM CO., LTD. (Japan)", no customer support is available for enquiries about purchases or usage in/from any countries other than Japan. Also, no foreign language other than Japanese is available. Replacements will be made under stipulation of the Elecom warranty, but are not available from outside of Japan.

ECLEAR corol  
 Instruction Manual For use in Hong Kong the Philippines, and Singapore  
 1st edition, September 7, 2017

**ELECOM**  
 ©2017 ELECOM Co., Ltd. All Rights Reserved.

22