

10

#### A Caution

Use the product after verifying that individual operation buttons operate

When you are using it for the first time or using it after not using it for a long period of time, please check that it operates correctly according to this

Stop using the product and consult a physician if the use of the product causes trong irritation, or rash, reddening, itch or other anomalies with the skin. will cause accidents or health problems.

Avoid touching the USB port with any part of your body such as a hand or a

It will cause an electric shock, fault or malfunction.

Do not insert any metallic object into the USB port. Doing so can cause heating and ignite fire.

Avoid excessive pulling or bending of the cable, or placing heavy objects on

It can cause cable damage, disconnection, and lead to a fire or electric shock.

No not use if the dedicated USB cable is damaged, or the USB port is loose Doing so can cause ignition of fire and electric shocks.

O not charge the product using a transformer, such as a travel converter. Doing so can cause heating and ignite fire.

O not charge the product in a car using a cigar socket or the like. Doing so can cause ignition of fire, heat and electric shocks.

Do not touch a special USB cable or a gel pad with wet hands. will cause an electric shock, failure or accidents.

Do not use a special cable for purposes other than charging the base unit. A special USB cable must not be used for communication purposes or for harging of other devices.

Securely insert the special USB cable to the root when charging. Charging with improper insertion can cause ignition of fire or electric shocks.

# Preparation [2 Point Pad]

Be sure to charge the product until it is fully charged prior to using the product (immediately after purchasing the product or when the product has not been used for long hours) or when

Charge time: Approx. 3.5 hours

#### Connect the Micro Type-B USB connector of the dedicated USB cable to the USB port on the main unit

Connect the Type-A USB connector of the dedicated USB cable to the

\* When correctly connected, you will hear the sound "pip", and the LED indicator on the main unit will blink or glow.

hen the battery falls below 80 when charged 80% or more; glu hen the battery is fully charged.	
Dedicated USB cable	USB connector slot
o PC 33.0 or USB3.1 port on PC te IEC60950 standard Dedicated USB cable TION:	Connect to USB Charger USB charger (Optional Parts: HCM-AC2A01WH)

• The use of a travel converter or any other power converter to charge the device may cause overheating or fire.

 The product cannot be operated while charging. · Repeatedly charging the base unit gradually shortens the duration of

operating time after a full charge. If the operation time becomes extremely short, the battery has expired but it is not replaceable.



government.

Install gel pads to the base unit.

heard

CAUTION:—

Use the designated gel pad only.

When replacing the gel pad

2 Take out the gel pad from the bag.

① Remove the main unit from the gel pad.

\* The operation methods of 1 Point Pad are the same as those of Wide Pad.

2 Turn OFF the power of the main unit, and make sure the LED indicator

3 Connect the main unit to the connector on the gel pad until a "click" is

When using for the first time, take the gel pad from the bag.

(Do not remove the protective film on the gel pad yet.)

# **About This Product**

#### Intended Use or Indications

This product is a low-frequency electronic pulse massager designed to prevent atrophy of numb muscles and provide massage benefits

The product is intended for use at home.

#### About Low-Frequency Electronic Pulse Massager

A Low-Frequency Electronic Pulse Massager relieves stiff muscles by sending weak low-frequency electrical impulses across the surface of the skin through electrodes placed on the body to induce muscle contraction and produce muscle pump action and vasodilation that improve blood flow. The low-frequency electrical impulses also relieve pain by stimulating nerves and blocking pain signals to your brain.

#### Standard Treatment Time

The standard treatment time is approximately 15 minutes for one treatment area. Continuing beyond 15 minutes can cause poor health. The product incorporates a timer that automatically turns off power when about 15 minutes are elapsed since the start of a treatment.

#### Effective Treatment Time

The treatment is more effective when administered after a bath. It is more effective in increasing blood flow when the body is warmed up.

#### CAUTION: -

Wipe all sweat or moisture from the skin prior to use.

# Placement of the Gel Pad [2 Point Pad]



\* On subsequent uses, peel it off the storage sheet. \* When removing a Wide Pad, pull both of the tabs to remove the pad.

Apply the gel pad to a treatment area.

Apply the gel pad firmly to the skin. \* If the gel pad separates from the skin, or the main unit is removed from the gel pad, the device automatically powers off.

## CAUTION: ----

Do not attach the gel pad over any metallic items such as a necklace or a body piercing.

#### Handling of gel pads

- Do not touch the adhesive surface of the gel pad. When the adhesiveness becomes weak, please see "How to Clean Gel Pad" (P. 20)
- Do not bend gel pads.

3 Turn OFF the power of the main unit, and make sure the LED indicator is off.

(4) Connect the main unit to the connector on the gel pad until a "click" is heard.

(Do not remove the protective film on the gel pad yet.)

#### Treatment

# Examples for applying gel pads



#### Storage

Please keep this product in an environment that meets the following conditions. Storage temperature: -10°C to 60°C

Storage humidity: 20 - 85% RH

#### Caution when Maintaining and Storing

. Do not use any benzene or paint thinner to service the product. · Do not store the product in locations described below.

- Locations that are exposed to direct sun light.
- In high temperature or high humidity areas,
- near water, or in dusty areas
- Locations with frequent vibration
- Locations where chemicals are stored or where
- corrosive gases are generated. · Place the product at a location that is out of reach of infants.
- If not using for a long period of time, store the product fully charged, and try to keep at room temperature (10°C - 30°C).
- . Charge the battery at least once every three months. If it is completely discharged, recharging might be impossible.
- Check Check the low-frequency electric pulse massager that is used for a long time. d accident, cut off the nove the dedicated USB Main unit ber cable. Ask the sales outlet to The Main Unit shows changes in ane or gives off a burning sm

21

Adjust the intensity level.	[Paste on stiff muscles.]	
<ul> <li>Select the desired strength from the 10 levels.</li> <li>* When the device is turned on, or when modes are changed, the intensity is set at level 1.</li> <li>• When [-] (Strong) button is pressed, you will hear the sound "pip", and the intensity increases by one level.</li> <li>• When [-] (Weak) button is pressed, you will hear the sound "pip-pip",</li> </ul>	1 Point Pad	
<ul> <li>and the intensity decreases by one level.</li> <li>When [+] (Strong) button is pressed at level 10, or when [-] (Weak) button is pressed at level 1, you will hear the sound "pip-pip-pip", and the intensity level does not change.</li> <li>Turn off the device.</li> </ul>		
After about 15 minutes of treatment, you will hear the sound "peep",	Arch	
and the device will automatically power off. To turn off the device during treatment, press and hold the power key, or [+] (Strong) button or [-] (Weak) button for about two seconds. If the gel pad separates from the skin, or the main unit is removed from the gel pad, the device automatically powers off.		



15

· Do not disposed of the device in regular household waste. The destroyed lithium ion battery inside a garbage

unctions and can lead to malfunction or accident.

22

his product contains a lithium-ion battery. Since lithium-ion batteries are

cyclable, valuable resources, we strongly encourage customers to

recycle. Lithium ion batteries are precious resources that can be recycled,

he procedure described below outlines the steps taken to dispose

product yourself can disable the product from sustaining its

of the product and is not intended for repairs. Disassembling the

Disposal

127

4d

M Warning

Fully discharge the battery.

the Main Unit.

④ Remove the battery.

Peel off the sticker on the Intensity dial.

① Insert a flat head screwdriver into the groove just beneath the Power button on

② Unscrew the screw fastening the base plate. ③ Cut off the power cord using a nipper from the black cord on the back of the base plate.

Be careful not to short-circuit the positive and

the terminal ends to isolate them.

negative terminals of the removed battery. Tape

Recycling of lithium ion batteries

Do not disassemble the battery when disposing of it.

Li-ion00 so we request for your cooperation in recycling.<br/>br>

truck causes a short circuit and may lead to a fire or heat generation.

How to remove the lithium-ion battery

Never disassemble the product except when disposing of the product.





### Troubleshooting

Problem	Cause		Solution
Power does not turn on	Battery is not charged fully or there is no po	/er left in battery	nd charge the device. +P.11
	The battery is being charged	Once the	battery has been charged, remove the special USB cable before using the product. +P.11
	Attach the gel pad firmly to the skin.	Turn off th	ne power then attach the gel pad to your skin correctly. +P.13
Power turns off soon after it is turned on Power turns off while product is in use	Battery is not charged fully or there is no po	/er left in battery	nd charge the device. +P.11
rower tams on while product is in use	Main unit and gel pad are not connected co	ectly to each other Turn off th	e device, and reconnect the main unit and the gel pad. ♦P.12 • P.13
	A gel pad is not properly sealed onto the sk	Turn off th	ne power then attach the gel pad to your skin correctly. +P.13
The device cannot be charged	Battery completely discharged after storing	roduct for a long period The produ	ct can no longer be used. Charge the product at least once in about three months to prevent a complete discharge. +
Gel pad does not stay on the skin	Do not remove the protective film from the ad	esive surface of the gel pad.	he protective film from the adhesive surface of the gel pad. ♦P.13
	Adhesive surface of the gel pad is dirty	Run a sm	all amount of water on the surface and rub it with your fingertips for several seconds. +P20
	Using immediately after rinsing with water	Shake off	the excess water and air dry the adhesive surface. +P.20
	An unpleasant sensation is felt during treatm	ent Gel pads	are consumables. When the adhesive surface has deteriorated, stop using and purchase optional pads. +
The adhesive surface of the gel pad detaches or shifts	Excess amount of sweat or water on adhesi	e surface of gel pad	are consumables. When the adhesive surface has deteriorated, stop using and purchase optional pads.
No / weak stimulus feit	The gel pad is not in close contact with the	kin Attach the	a gel pad to your skin firmly. ♦P.13
	Gel pads are overlapped when they are app	ed Attach it t	peing careful not to overlap with another gel pad. ♦P.13
	Adhesive surface of the gel pad is dirty	Run a sm	all amount of water on the surface and rub it with your fingertips for several seconds. +P20
	The gel pad is not properly connected	Connect	t correctly by pushing in until it clicks. +P.12
	The strength adjustment is at a weak setting	Adjust to	stronger intensity. ♦P.15
	Insufficient charging or depleted battery	Charge th	ie battery. ♦P.11
	The adhesive surface of the gel pad is dirty	r damaged The gel p	ad is a consumable. When the adhesive surface has deteriorated, stop using and purchase optional pads.
Skin flares/ The skin becomes irritated	Treatment time is too long	Use the d	evice up to 15 minutes on one treatment area, and remove the gel pad from the skin after treatment. +P.15
The skin becomes initiated	The gel pad is not in close contact with the	kin Attach the	a gel pad to your skin firmly. ♦P.13
	Adhesive surface of the gel pad is dirty or d	Run a sm	all amount of water on the surface and rub it with your fingertips for several seconds. +P20
	An unpleasant sensation is felt during treatm	ent The gel p	ad is a consumable. When the adhesive surface has deteriorated, stop using and purchase optional pads.

# **Product Specifications**

Brand name
Classification
General name
Type of medical equipmen
Medical equipment certification number
Power source voltage
Built-in battery
Number of charge cycles
Charge time
Operating time
Maximum output current
Rated output voltage
Fundamental frequency
Output pulse width
Power consumption
Timer
Main unit dimensions
Cable length
Main unit weight
Operating temperature and
humidity ranges Storing environment
temperature and humidity
Marketing authorization holder
Manufacturer
Country of origin
1 According to JIS (

- \*4 Depends on operation and environment

# After use [2 Point Pad]

Pull the tab to remove the gel pad;

do not touch the adhesive surface of

\* For the pair gel, place on two sides of the storage sheet.

Store the gel pad in a place free from direct sunlight, high humidity and high temperature.

26

19

Store the Device

the gel pad.

storage sheet.



18

_	
	Low-Frequency Electronic Pulse Massager P01
	Equipment 78 Electric therapy apparatus for household use
	Low-Frequency Electronic Pulse Massager for Home Use (Code: 70986000)
	Controlled medical equipment
	228ADBZX00037000
	DC5.0V
	Lithium-ion battery (40 mAh *1 *2)
	Approx. 500 times * 1
	Approx. 3.5 hours * 3
	Approx. 150 minutes (when fully charged) *4
	10 mA or less
	Approx. 32V
	Approx. 2 - 550Hz
	Approx. 200 µ s
	Approx. 0.2 W
	Approx. 15 minutes
	Approx.
	20 cm
	Approx. 13 g
	0°C to 40°C; 20 to 85% RH
	0°C to 40°C; 20 to 85% RH
	Elecom Healthcare Co., Ltd. LA Tower 8F, 4-1-1 Fushimicho, Chuo-ku, Osaka City, Osaka Prefecture
	Zhangzhou Easepal Industrial Corporation
1	China

C 8711

\*2 With protection function for over-charging, over-discharging and over-voltage \*3 Standard when charging fully discharged battery to full power

### Maintenance [2 Point Pad]

To care for the gel pad, disconnect it from the main unit.

#### Clean A Gel Pad



- Gel pad adhesion is weakened · Treatment stimulation feels weaker
- An unpleasant sensation is felt during treatment
- Gel pads are contaminated
- The gel pad does not stick to the storage sheet

Replace the gel pad if you feel there is not enough/too much

stimulus during use even after caring for the gel pad.

- ① Run a small amount of water on the surface and rub it gently with your
- fingertips for several seconds.

#### \* Do not pour on too much water. It will cause loss of adhesive strength or damage to the adhesive surface.



#### 2 Pull the tab and drain the water of f, and let the pad dry naturally.

- \* If not dried thoroughly, adhesion decreases.
- \* Do not wipe the adhesive surface with a tissue or cloth.
- \* Avoid direct sunlight.

#### Care of the Main Unit

· Wipe dirt off the main unit with soft cloth.

#### - \Lambda CAUTION: —

Be sure to prevent any water from entering into the base unit interiors, as well as the USB connector insertion receptacle.

A customer who purchases outside Japan should contact the local retailer in the country of purchase for enquiries. In "ELECOM CO., LTD. (Japan)", no customer support is available for enquiries about purchases or usage in/from any countries other than Japan. Also, no foreign language other than Japanese is available. Replacements will be made under stipulation of the Elecom warranty, but are not available from outside of Japan.

ECLEAR Refree HCM-P01 Series User Manual
1st edition, March, 2018 ELECOM CO.,LTD.
<ul> <li>The copyright of this manual is owned by ELECOM Co., Ltd.</li> </ul>
<ul> <li>Unauthorized reproduction/reprint of all or part of this manual is prohibited.</li> </ul>
· If you have comments or questions about this User Manual, please contact the dealer.
<ul> <li>The specifications and appearance of this product may be changed without prior notice for product improvement purposes.</li> </ul>
<ul> <li>We shall bear no responsibility for any device failure or malfunction of other devices resulting from the use of this product.</li> </ul>
· Permission for export or service transaction under the Foreign Exchange and Foreign Trade Control
· Act is required in order to export this product or parts of this product that constitute strategic
materials or services.
<ul> <li>Company names, product names, and other names in this manual are generally trademarks or registered trademarks.</li> </ul>