

Safety Precautions

Prohibited action

English (EN)

Mandatory action

Situation that needs attention

WARNING

If a foreign object (such as water or metal chip) enters the product, immediately stop using the product and remove the batteries. If you continue to use the product under these conditions, it may cause a fire or electric shock.

If an abnormality is found with this product (such as heat, smoke or an unexpected smell coming from the product), immediately stop using the product and remove the batteries while paying careful attention not to get burned. After doing so, contact the retailer from whom you purchased the product. If you continue to use the product under these conditions, it may cause a fire or electric shock.

Do not drop the product, nor subject it to strong physical shocks. In the event of the product becoming damaged, immediately stop using the product and remove the batteries. If you continue to use the product under these conditions, it may cause a fire or electric shock.

Do not attempt to disassemble, modify or repair this product by yourself, as this may cause a fire, electric shock or product damage.

Do not put this product in fire, as the product may burst, resulting in a serious fire or injury.

CAUTION

Do not place this product in any of the following environments:

- In a car exposed to sunlight or a place exposed to direct sunlight.
- In a place that becomes hot, such as around a heater.
- In a moist place or a place where condensation may occur.
- In an uneven place or a place exposed to vibration.
- In a place where a magnetic field is generated (such as near a magnet).
- In a dusty place.

This product does not have a waterproof structure. Use and store this product in a place where the product body will not be splashed with water or other liquid. Rain, water mist, juice, coffee, steam or sweat may also cause product damage.

Do not use this product for any purpose other than a smartphone controller.

Do not use this product with any device that may significantly be affected in the case of this product malfunctioning.

When using it continuously for a long period, take appropriate breaks.

When you no longer need to use this product and the battery, be sure to dispose of them in accordance with the local ordinances and laws of your area.

Tindakan Pencegahan dan Keselamatan

Tindakan yang dilarang Bahasa Indonesia (ID)

Tindakan wajib

Situasi yang membutuhkan perhatian

PERINGATAN

Jika objek asing (air, serpihan logam, dll) memasuki produk, segera hentikan menggunakan produk dan lepaskan baterai. Jika Anda terus menggunakan produk dalam kondisi ini, kebakaran atau sengatan listrik dapat terjadi.

Jika kelebihan arus ditermukan pada produk ini (misalnya panas, berarap, atau bau yang tidak diharapkan muncul dari produk), segera hentikan menggunakan produk dan lepaskan baterai sebelum berhenti agar tidak terbakar. Setelah melakukannya, hubungi peritel atau tempat Anda membeli produk. Jika Anda terus menggunakan produk dalam kondisi ini, kebakaran atau sengatan listrik dapat terjadi.

Jangan menjatuhkan atau memukul produk ini. Jika produk rusak, segera hentikan menggunakan produk dan matikan mouse. Jika Anda terus menggunakan produk dalam kondisi ini, hal ini dapat menyebabkan kebakaran atau sengatan listrik.

Jangan membongkar, melakukan perubahan atau mencoba memperbaiki stasiun dok. Hal tersebut dapat menyebabkan kebakaran, sengatan listrik atau kerusakan.

Jangan meletakkan produk ini dalam api, karena produk bisa meledak, mengakibatkan kebakaran atau cedera.

PERHATIAN

Jangan meletakkan produk ini di salah satu lingkungan berikut:

- Pada tempat yang lembab atau dimana kondensasi dapat terjadi.
- Pada tempat yang tidak jauh dari sumber panas, seperti sekelling pemanas/heater.
- Pada tempat yang lembab atau dimana kondensasi dapat terjadi.
- Di tempat yang tidak rata atau tempat yang terkena getaran.
- Pada tempat yang tidak jauh dari medan magnet, seperti sekelling magnet.
- Di tempat berdebu

Produk ini tidak memiliki struktur tahan air. Gunakan dan simpan produk ini di tempat di mana badan produk tidak akan tersiram air atau cairan lainnya. Hujan, kabut air, jus, kopi, uap atau keriting juga dapat menyebabkan kerusakan produk.

Jangan gunakan produk untuk maksud lain selain sebagai controller ponsel pintar.

Jangan gunakan produk ini dengan perangkat apa pun yang dapat terpengaruh secara signifikan jika produk tidak berfungsi.

Saat digunakan terus-menerus dalam jangka waktu yang lama, harap hentikan penggunaan selama beberapa saat.

Bila Anda tidak lagi menggunakan produk dan baterai ini, pastikan untuk membuangnya sesuai dengan peraturan daerah dan hukum di wilayah Anda.

■ Batteries

Please use either alkaline batteries, manganese batteries or nickel-metal hydride rechargeable batteries. Do not mix different types of batteries together or old batteries with fresh ones. Doing so may cause battery leakage and failure. If this product is not going to be used for a long period of time, remove the battery to avoid battery leakage and failure.

Cleaning the Product

If the product body becomes dirty, wipe it with a soft, dry cloth. Use of a volatile liquid (such as paint thinner, benzene or alcohol) may affect the material quality and color of the product.

Cautions for Wireless Equipment

This product is wireless equipment using the entire range of the 2.4 GHz band and it is possible to avoid the band of mobile object identification systems. FHS-SS is used for the radio wave method. The interference distance is 10 m. The 2.4 GHz band is also used by medical equipment, Bluetooth, and wireless LAN equipment conforming to the IEEE802.11b/1g/1n standard.

Before using this product, check that there are no other "radio stations" operating nearby.

If electromagnetic interference occurs between this product and other "radio stations", move this product to another location or stop using this product.

"Other "radio stations" refer to industrial, scientific and medical devices using the 2.4 GHz band, as this product does, other stations of this type, licensed radio station premises for a mobile object identification system that is used in factory production lines, certain non-licensed low power radio stations and amateur radio stations.

WARNING

Do not place this product in any of the following environments:

- In a car exposed to sunlight or a place exposed to direct sunlight.
- In a place that becomes hot, such as around a heater.
- In a moist place or a place where condensation may occur.
- In an uneven place or a place exposed to vibration.
- In a place where a magnetic field is generated (such as near a magnet).
- In a dusty place.

This product does not have a waterproof structure. Use and store this product in a place where the product body will not be splashed with water or other liquid. Rain, water mist, juice, coffee, steam or sweat may also cause product damage.

Do not use this product for any purpose other than a smartphone controller.

Do not use this product with any device that may significantly be affected in the case of this product malfunctioning.

When using it continuously for a long period, take appropriate breaks.

When you no longer need to use this product and the battery, be sure to dispose of them in accordance with the local ordinances and laws of your area.

Limitation of Liability

In no event will ELECOM Co., Ltd be liable for any lost profits or special, consequential, indirect, punitive damages arising out of the use of this product.

ELECOM Co., Ltd will have no liability for any loss of data, damages, or any other problems that may occur to any devices connected to this product.

취급 주의 사항

(한국어 (KO))

● 금지 사항
● 의무 이행 사항
● 주의 사항

경고

● 본 제품에 물이나 금속 파편 등의 이물질이 들어간 경우는 즉시 사용을 중지하고 본 제품에서 전지를 빼 주십시오. 그 상태로 사용하면 화재나 감전의 원인이 됩니다.

● 본 제품이 발열하거나 증기나 가스를 발생하는 등의 이상이 있는 경우 사용을 중지하고 본 제품의 전원을 차단해주시오. 그 상태로 사용하면 화재나 감전의 원인이 됩니다.

● 본 제품은 물에 빠뜨렸거나, 부딪히거나 하지 않도록 하십시오. 그 상태로 사용하면 화재나 감전의 원인이 될 수 있습니다.

● 본 제품을 분해, 변경 또는 수리하지 마십시오. 화재, 감전 또는 고장의 원인이 될 수 있습니다.

● 본 제품을 불 속에 넣지 마십시오. 파열로 인해 화재나 상해의 원인이 될 수 있습니다.

주의

● 본 제품을 다음과 같은 곳에서 보관하지 마십시오.

• 햇빛에 노출된 차량이나 사파리agan에 노출된 장소
• 하지 주변과 같은 곳에 거치워지는 곳.
• 결로가 생길 수 있는 쪽을 향하는 곳.
• 평坦하지 않은 곳, 진흙이 발생하는 곳.
• 자갈과 같은 자가장치가 발생하는 곳.
• 먼지가 많은 곳

● 본 제품은 방수 구조가 아닙니다. 물 등의 액체가 뛰어나는 곳에서 사용 혹은 보관해 주십시오. 비, 뛰는 물방울, 주스, 커피, 증기, 링통 등 고장의 원인이 될 수 있습니다.

● 이 제품은 스마트폰 컨트롤러가 아닌 다른 용도로 이용하지 마십시오.

● 본 제품의 오동작으로 인해 중대한 영향을 미칠 위험이 있는 기기에서는 사용하지 마십시오.

● ELECOM은 not liable for any accident or any indirect or consequential damage incurred due to the failure of this product.

책임의 제한

● In no event will ELECOM Co., Ltd be liable for any lost profits or special, consequential, indirect, punitive damages arising out of the use of this product.

● ELECOM Co., Ltd will have no liability for any loss of data, damages, or any other problems that may occur to any devices connected to this product.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

● 본 제품 및 전자기기는 환경으로 인해 사고나 사회적 손해가 발생해 폐하는 어떠한 책임도 지지 않습니다. 이 점 양해 바랍니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한

● ELECOM 주식회사는 제품의 사용으로 인한 특별 손해, 결과적 손해, 간접적 손해, 저발적 손해, 이익 상실에 대한 보상 책임을 시집 않습니다.

● ELECOM 주식회사는 제품과 연결된 장치에서 일어날 수 있는 데이터 손실, 오류 또는 기타 문제에 대해 어떠한 보증도 하지 않습니다.

책임의 제한