

7 Inserting battery

M-DWM01DBBK

M-DWS01DBBK/M-DWL01DBBK

The orientation for battery may vary depending on the model you purchased. Insert the battery in the correct direction.

4 Installing special driver

In Windows, you can assign functions to buttons or configure macros and the detailed DPI specific to the X/Y axis by downloading and installing the special driver from our website.

- In Windows, the configuration for this product can not be changed with the Elecom Mouse Assistant.

- 2 Turning power on
- 1 Double-click the ELECOM DUAL series Mouse Driver (.exe) you have just downloaded.

- 3 **Connecting to PC**

 - 1 **Start the PC.**
Wait until it becomes ready to operate.
 - 2 **Insert the USB connector of this product into the USB port of the PC.**
You can use any USB ports.
 - ⚠ Ensure the correct orientation and plug-in location of the connector.
 - ⚠ If it felt hard to insert, do not force it and check the shape and orientation of the connector. Forcibly inserting the connector may damage the connector, and there is a risk of injury.
 - ⚠ Do not directly touch the terminal area of the USB connector.
- 4 **Click "Close".**

- 5 **The Configuration screen is shown and your system attempts to recognize this product.**

- 6 **Installation of the special driver is completed when the Configure special driver screen appears.**
Now, this product is ready to use.

temperature/humidity _____

以下 Windows 10 的截屏。您的屏幕可能会因操作系统而异，但安装过程是完全相同的。

基本规格

1 전전지 삽입 M-DWM01DBBK M-DWS01DBBK/M-DWL01DBBK 전전지 방향은 구멍안 모양에 따라 다릅니다. 전전지를 올바른 방향으로 삽입합니다.	4 특수 드라이버 설치 Windows의 경우, 본사 웹사이트에서 특수 드라이버를 다운로드하고 설치하여 버튼에 기능을 할당할 때 마크로 및 XY 축에 대한 상세 DPI를 구성할 수 있습니다. • 구성에서 본 제품의 구성은 Elecom Mouse Assistant로 변경할 수 없습니다.
---	--

2 전원 켜기

- 3 PC 접속

- 4 "닫기"를 클릭 합니다.

- 5 구성 화면이 표시되고 시스템이 제품 인식을 시도합니다.
- 6 특수 드라이버 구성 화면이 표시되면 특수 드라이버 설치가 완료됩니다. 이제 제품을 사용할 준비가 되었습니다.

양식 온도/ 습도	5°C ~ 40°C / 최고 90%RH (결로 없음)
-----------	-------------------------------

以下為 Windows®10 的螢幕截圖。視作業系統而定，您的畫面可能有不同，但操作程序是相同的。

規格									
