


User Manual

Wired in-ear headphones with microphone,
Ø3.5 mm 4-pole plug

Thank you for purchasing the product. Read the manual before use and use the product correctly.

How to use


■ Wired in-ear headphones with microphone, Ø3.5 mm 4-pole plug



*M-size ear tips are pre-attached to the product. If they do not fit, replace them with S- or L-size ear tips.

Ø3.5 mm 4-pole mini-plug

- The center button cannot be used to answer or end calls for Internet calling services such as Microsoft Teams™.
- Some smartphones equipped with a Ø3.5 mm mini-jack may not be compatible with the product.
- Insert the plug firmly all the way into the jack. If the plug is loosely inserted, you may not hear any sound.
- If the headphones do not fit your ears properly, for example, if they do not seal well or if they fall out easily, replace the ear tips with a different size.
- The product cannot be used with devices that do not have a Ø3.5 mm mini-jack.



■ Center button controls

	● Press quickly once
	▬ Press and hold once (2 seconds or more)
Answer/End Call	●
Reject Call (while ringing)	▬
Play/Pause	●
Next Track	● ●
Previous Track or Restart Current Track	● ● ●
Activate Voice Assistant	▬

*Compatibility with all devices, OS versions, or applications is not guaranteed.

Safety precautions

WARNING

- Do not disassemble or modify the product under any circumstances.
- Do not use the headphones while riding a bicycle or motorcycle, or while driving a car. Doing so may cause traffic accidents.
- When using the product while walking, pay close attention to your surroundings. Failure to do so may cause traffic accidents.
- Do not use the product in locations where failure to hear surrounding sounds could be dangerous, such as railroad crossings, train platforms, roads with traffic, and construction sites.
- There is a risk that children may accidentally swallow it and choke. Keep the product out of the reach of children.

CAUTION

- Do not use the headphones at a high volume for a long time. Doing so may have an adverse effect on your hearing. Always use the product at a moderate volume.
- If you feel that the headphones are irritating your skin, stop using them immediately and consult a physician.
- Be sure to firmly attach the ear tips to the nozzles so that they do not come off. If an ear tip comes off and remains in your ear, do not try to remove it forcibly but consult a physician.
- Do not place the product near heating appliances, in high-temperature or dusty locations, in direct sunlight, or in places where it may be exposed to water. Doing so may cause malfunction.
- Do not subject the product to strong impact.

Handling precautions

- Be considerate of others when using the product.
- When disconnecting the headphones, always hold the connector, not the cable. Pulling on the cable may cause cable damage or malfunction.
- Read the manual of any connected device. We do not provide instructions for the use of connected devices.
- Do not wrap the cable around the device. Doing so may cause cable damage or malfunction.

Maintenance

- If the main unit or cable becomes dirty with sweat, hair products, or similar substances, wipe it clean with a dry cloth promptly after use. Leaving dirt on the product may cause deterioration of parts, which could lead to cable damage or malfunction.
- If the product is heavily dirty, wipe it with a soft cloth lightly moistened with water or a small amount of neutral detergent.
- Note that volatile liquids such as thinner, benzine, and alcohol may cause deterioration or discoloration.
- If the connector becomes dirty, wipe it with a dry cloth. Using the product while the connector is dirty may result in sound interruptions or noise.
- If the ear tips become dirty, wipe them with a dry cloth.

Limitation of Liability

- In no event will ELECOM Co., Ltd. be liable for any lost profits or special, consequential, indirect, punitive damages arising out of the use of this products.
- ELECOM Co., Ltd. will have no liability to any loss of data, damages, or any other problems that may occur to any devices connected to this product.

Global Support



A customer who purchases outside Japan should contact the local retailer in the country of purchase for inquiries.

In "ELECOM CO., LTD. (Japan)", no customer support is available for inquiries about purchases or usage in/from any countries other than Japan. Also, no language other than Japanese is available. Replacements will be made under stipulation of the Elecom warranty.

<https://www.elecom.co.jp/r/s536>

ELECOM CO., LTD.

Fushimimachi 4-1-1, Chuo-ku, Osaka City
www.elecom.co.jp/global/

- The images are for illustration purposes only and may differ from your actual product.
- ELECOM CO., LTD. owns the copyright of this manual.
- Unauthorized copying and/or reproducing of all or part of this manual is prohibited.
- If you have any concerns or question regarding this manual, please contact the retailer from whom you purchased this product.
- In order to make improvements to this product and for improved safety, the colors and specifications are subject to change without prior notice.
- We shall bear no responsibility for any device failure or malfunction of other devices resulting from the use of this product.
- When exporting this product, check the export regulations for the country of origin.
- Microsoft Teams is registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.
- The company and product names on the packaging and the manual are, in general, trademarks or registered trademarks of their respective companies.

Wired in-ear headphones with microphone, Ø3.5 mm 4-pole plug
Manual, Safety precautions, and Compliance with regulations, 1st edition, August, 2026

Model: EHP-F17CM

©2026 ELECOM Co., Ltd. All Rights Reserved.
MSC-EHP-F17CM_W01