


取扱説明書

マイク付き 有線イヤホン
Type-C™ カナル型

お買い上げありがとうございます。ご使用前にこの取扱説明書を必ずお読みのうえ、正しくご使用ください。

使用方法


■マイク付き 有線イヤホン Type-C™ カナル型



※本体に装着済みのイヤーピースはMサイズです。サイズが合わない場合はSサイズまたはLサイズに付け替えることができます。

対応機器の USB Type-C ポートに本製品を接続します。

※本製品を対応機器に接続した際、認識されるまでに約 2 秒かかる場合があります。



■センターボタンでの操作

- 1 回短押し
- ▬ 1 回長押し (2 秒以上)

着信応答 / 通話終了	●
音楽再生 / 一時停止	●
次の曲の頭出し	●●
前の曲または再生中の曲の頭出し	●●●
音声アシスタントの起動	▬

※全ての機器、OS バージョン、アプリケーションなどとの完全な互換性を保証するものではありません。

安全上のご注意

警告

- 本製品を分解、改造することは絶対におやめください。
- 自転車、オートバイ、自動車の運転中には、イヤホンを使用しないでください。交通事故の原因となります。
- 歩行中にご使用になる時は、周囲の環境に十分注意してください。交通事故の原因となります。
- 踏切、駅のホーム、自動車の通る道、工事現場など、周囲の音が聞こえないと危険を伴う場所では使用しないでください。
- 本製品(イヤホン・イヤピース)は、食べ物ではありません。お口に入れないようにしてください。
- 誤ってお子様飲み込み、気管に詰まるおそれがあります。本製品を子供の手が届く範囲に保管しないでください。

注意

- イヤホンを大音量で長時間使用しないでください。聴力に悪い影響を与える可能性があります。常に適度な音量でご使用ください。
- イヤホンが肌に合わないと感じた時は、早めに使用を中止し、医師に相談してください。
- イヤピースがはずれないよう、ノズル部にしっかりと取り付けてください。万一、イヤピースがはずれて耳に残った時は、無理に取り出さず医師の診察を受けてください。
- 暖房機器の近く、高温やホコリの多い場所、直射日光の当たる場所、水のかかる場所には、置かないでください。故障の原因になります。
- 強い衝撃を与えないでください。

取扱い上のご注意

- ご使用の際は、周囲の迷惑にならないようご注意ください。
- イヤホンのコネクターを抜く時は、コードを引っ張らないで必ずコネクターを持って抜いてください。コードを引っ張って抜くと、断線など故障の原因となります。
- 接続する機器の取扱説明書も必ずお読みください。各機器の使用方法は当社ではサポートしていません。
- コードを機器に巻きつけないでください。断線など故障の原因となります。

お手入れについて

- 本体やコードが汗や整髪料などで汚れたときは、使用后すみやかに乾いた布で拭いてください。汚れたまま放置すると、部品の劣化により断線など故障の原因となります。
- 特に汚れがひどい場合は、水または中性洗剤を少量含ませたやわらかい布で拭いてください。
- シンナー、ベンジン、アルコールなど揮発性の液体を使用すると、変質や変色を起こすおそれがあります。
- コネクターが汚れたときは、乾いた布で拭いてください。コネクターが汚れたまま使用すると、音とびや雑音が入る場合があります。
- イヤーピースが汚れたときは、乾いた布で拭いてください。

ユーザーサポートについて

選べる！充実サポート



LINE チャット でサポート

LINEアプリから
友だち追加でかんたんに
チャットでお問い合わせ！



Web チャット でサポート

ブラウザからでも
会員登録なしにお気軽
にご相談いただけます。



電話でサポート

エレコム製品サポートからカテゴリーごとに「よくあるご質問」や「サポートコミュニティ」をご紹介します。電話によるサポートが必要な場合は、サポートダイヤルをご用意しています。

連絡先はコチラから
8056.jp

商品に関するお問い合わせは

エレコム株式会社は、日本以外の国でのご購入、ご使用による問い合わせ、サポート対応はいたしかねます。

商品交換は保証規定に沿って対応いたしますが、日本以外からの商品交換は対応いたしかねます。In “ELECOM CO., LTD. (Japan)”, no customer support is available to inquiries about purchases or usage in/from any other countries than Japan.

Replacement will be made under stipulation of the Elecom warranty, but not available from outside of Japan.

※イラストはイメージです。実際の商品とは異なる場合がありますので、あらかじめご了承ください。

※本書の著作権は、エレコム株式会社が保有しています。

※本書の内容の一部または全部を無断で複製 / 転載することを禁止させていただきます。

※本書の内容に関するご意見、ご質問がありましたら、エレコム製品サポートまでご連絡願います。

※本製品の仕様および外観は、製品の改良のため予告なしに変更する場合があります。

※本製品を使用したことによる他の機器の故障や不具合等については、責任を負いかねますのでご了承ください。

※本製品のうち、戦略物資または役務に該当するものの輸出にあたっては、外為法に基づく輸出または役務取引許可が必要です。

※USB Type-C and USB-C are trademarks of USB Implementers Forum.

※LINEおよびLINEヤフーロゴは、LINEヤフー株式会社の登録商標です。

※その他本書に記載されている会社名・製品名等は、一般に各社の商標ならびに登録商標です。

保証規定

■保証期間

1年間

■保証対象

保証対象は本製品の本体・本製品の動作に起因する部分のみとさせていただきます。取扱説明書および消耗品は対象外です。

■保証内容

1. 弊社が定める保証期間(本製品ご購入日から起算されます。)内に、適切な使用環境で発生した本製品の故障に限り、無償で本製品を修理または交換いたします。
※保証期間を超過している場合、有償となります。

■無償保証範囲

2. 以下の場合には、保証対象外となります。
 - (1) 購入証明書および故障した本製品をご提出いただけない場合。
※購入証明書は、購入日、購入店、型番が確認できるもの(レシート・納品書など)を指します。
 - (2) 購入証明書に偽造・改変などが認められた場合。
 - (3) 中古品として本製品をご購入された場合。(リサイクルショップでの購入、オークション購入での中古品を含む)
 - (4) 弊社および弊社が指定する機関以外の第三者ならびにお客様による改造、分解、修理により故障した場合。
 - (5) 弊社が定める機器以外に接続、または組み込んで使用し、故障または破損した場合。
 - (6) 通常一般家庭、一般オフィス内で想定される使用環境の範囲を超える温度、湿度、振動などにより故障した場合。
※使用環境条件が記載されている製品については製品記載の範囲を超えないこと。
 - (7) 本製品を購入いただいた後の輸送中に発生した衝撃、落下などにより故障した場合。
 - (8) 地震、火災、落雷、風水害、その他の天変地異、公害、異常電圧などの外的要因により故障した場合。
 - (9) 接続されている他の機器に起因して、本製品に故障、損傷が生じた場合。
 - (10) ソフトウェア(ファームウェア、ドライバ他)のアップデート作業によって故障、障害が生じた場合。
 - (11) 本製品の、パッケージ、取扱説明書、ならびに弊社ホームページなどに記載の使用方法、および注意に反するお取り扱いによって生じた故障、損傷の場合。
 - (12) その他、無償修理または交換が認められない事由が発見された場合。

■修理

3. 修理のご依頼は、購入証明書をお買い上げいただいた製品一式(付属品、セット品含む)に添えて、お買い上げの販売店にお持ちいただくか、弊社修理センターに送付してください。
4. 弊社修理センターへご送付いただく場合の送料はお客様のご負担となります。(返送時の送料は弊社が負担いたします。)また、ご送付いただく際、適切な梱包の上、紛失防止のため受渡の確認できる手段(宅配や簡易書留など)をご利用ください。なお、弊社は運送中の製品の破損、紛失については一切の責任を負いかねます。
5. 同機種での交換ができない場合は、保証対象製品と同等またはそれ以上の性能を有する他の製品と交換させていただく場合があります。
6. 保証期間内にて修理、交換により交換された、旧部品または旧製品などは返却いたしかねます。
7. 記憶メディア・ストレージ製品において、修理センターにて製品交換を実施した際にはデータの保全は行わず、全て初期化いたします。記憶メディア・ストレージ製品を修理に出す前には、お客様ご自身でデータのバックアップを取っていただきますようお願いいたします。
8. 修理期間中における代替機および貸出機のご用意はありません。

■免責事項

9. 本製品の故障について、弊社に故意または重大な過失がある場合を除き、弊社の債務不履行および不法行為などの損害賠償責任は、本製品購入代金を上限とさせていただきます。
10. 本製品の故障に起因する派生的、付随的、間接的および精神的損害、逸失利益、ならびにデータ損害の補償などについては、弊社は一切責任を負いかねます。
11. データを取扱う際には自己責任において、必ず定期的なバックアップを取ってください。本製品の故障または使用によって生じた、保存データの消失、破損などについては一切保証いたしません。

■有効範囲

12. この保証規定は、日本国内においてのみ有効です。エレクトロニクス株式会社は、日本以外の国でのご購入・ご使用による問い合わせ・サポート対応はいたしかねます。
This warranty is valid only in Japan. In "ELECOM CO., LTD. (Japan)", no customer support is available for enquiries about purchases or usage in/from any countries other than Japan.


User Manual

USB Type-C® wired in-ear headphones with microphone

Thank you for purchasing the product. Read the manual before use and use the product correctly.

How to use


■ USB Type-C wired in-ear headphones with microphone



*M-size ear tips are pre-attached to the product. If they do not fit, replace them with S- or L-size ear tips.

Connect the product to the USB Type-C port of a compatible device.

*It may take approximately 2 seconds after connection for the compatible device to



■ Center button controls

	● Press quickly once
	▬ Press and hold once (2 seconds or more)
Answer/End Call	●
Play/Pause	●
Next Track	● ●
Previous Track or Restart Current Track	● ● ●
Activate Voice Assistant	▬

*Compatibility with all devices, OS versions, or applications is not guaranteed.

Safety precautions

WARNING

- Do not disassemble or modify the product under any circumstances.
- Do not use the headphones while riding a bicycle or motorcycle, or while driving a car. Doing so may cause traffic accidents.
- When using the product while walking, pay close attention to your surroundings. Failure to do so may cause traffic accidents.
- Do not use the product in locations where failure to hear surrounding sounds could be dangerous, such as railroad crossings, train platforms, roads with traffic, and construction sites.
- This product (headphones and ear tips) is not food. Do not put it in your mouth.
- There is a risk that children may accidentally swallow it and choke. Keep the product out of the reach of children.

CAUTION

- Do not use the headphones at a high volume for a long time. Doing so may have an adverse effect on your hearing. Always use the product at a moderate volume.
- If you feel that the headphones are irritating your skin, stop using them immediately and consult a physician.
- Be sure to firmly attach the ear tips to the nozzles so that they do not come off. If an ear tip comes off and remains in your ear, do not try to remove it forcibly but consult a physician.
- Do not place the product near heating appliances, in high-temperature or dusty locations, in direct sunlight, or in places where it may be exposed to water. Doing so may cause malfunction.
- Do not subject the product to strong impact.

Handling precautions

- Be considerate of others when using the product.
- When disconnecting the headphones, always hold the connector, not the cable. Pulling on the cable may cause cable damage or malfunction.
- Read the manual of any connected device. We do not provide instructions for the use of connected devices.
- Do not wrap the cable around the device. Doing so may cause cable damage or malfunction.

Maintenance

- If the main unit or cable becomes dirty with sweat, hair products, or similar substances, wipe it clean with a dry cloth promptly after use. Leaving dirt on the product may cause deterioration of parts, which could lead to cable damage or malfunction.
- If the product is heavily dirty, wipe it with a soft cloth lightly moistened with water or a small amount of neutral detergent.
- Note that volatile liquids such as thinner, benzine, and alcohol may cause deterioration or discoloration.
- If the connector becomes dirty, wipe it with a dry cloth. Using the product while the connector is dirty may result in sound interruptions or noise.
- If the ear tips become dirty, wipe them with a dry cloth.

Limitation of Liability

- In no event will ELECOM Co., Ltd. be liable for any lost profits or special, consequential, indirect, punitive damages arising out of the use of this products.
- ELECOM Co., Ltd. will have no liability to any loss of data, damages, or any other problems that may occur to any devices connected to this product.

Global Support



A customer who purchases outside Japan should contact the local retailer in the country of purchase for inquiries.

In "ELECOM CO., LTD. (Japan)", no customer support is available for inquiries about purchases or usage in/from any countries other than Japan. Also, no language other than Japanese is available. Replacements will be made under stipulation of the Elecom warranty.

<https://www.elecom.co.jp/r/s536>

ELECOM CO., LTD.

Fushimimachi 4-1-1, Chuo-ku, Osaka City
www.elecom.co.jp/global/

- The images are for illustration purposes only and may differ from your actual product.
- ELECOM CO., LTD. owns the copyright of this manual.
- Unauthorized copying and/or reproducing of all or part of this manual is prohibited.
- If you have any concerns or question regarding this manual, please contact the retailer from whom you purchased this product.
- In order to make improvements to this product and for improved safety, the colors and specifications are subject to change without prior notice.
- We shall bear no responsibility for any device failure or malfunction of other devices resulting from the use of this product.
- When exporting this product, check the export regulations for the country of origin.
- USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
- The company and product names on the packaging and the manual are, in general, trademarks or registered trademarks of their respective companies.

USB Type-C wired in-ear headphones with microphone

Model: EHP-DF19CM

Manual, Safety precautions, and Compliance with regulations, 1st edition, June, 2026

©2026 ELECOM Co., Ltd. All Rights Reserved.
MSC-EHP-DF19CM_W01